

# Third Party Access - Series IV

## Third Party Access with Series IV Monitors

The **Third Party Access - Series IV** software provides the ability to control, upload and download data, directly from Instantel® Minimate Pro4™ or Minimate Pro6™ monitors, without using the Blastware® Compliance Module.

Third Party Access provides a comprehensive set of commands to directly access a Series IV monitor. This is done by an Application Program Interface (API), provided in the form of a Dynamic Linked Library (DLL). Exported data can be further analyzed within a spreadsheet or leveraged using the Internet, automating the process of transferring vibration data directly from the Series IV unit to a web site, for viewing by approved stakeholders.

The API was developed using the .NET 4.0 Framework and can be integrated into a project using programming languages such as C# or VB.NET. Only the Blastware Compliance Module is supported; the program maintains the proprietary Instantel Event format and security features. Event data can be exported into the XML, CSV or ASCII file formats.

The Third Party Access – Series IV programming software is only compatible with the Instantel Minimate Pro4 and Minimate Pro6 monitors, and provides the same functionality as the Blastware Compliance Module.



### Third Party Access - Series IV Commands

Item	Description
1.	Set communication parameters to access the unit.
2.	Read the unit Status.
3.	Read and write the Date and Time to the unit.
4.	Read and write the Compliance Setup File of the unit.
5.	Control the Monitor Scheduler calendar commands.
6.	Read and write the Auto Call Home configuration settings.
7.	Start and Stop Monitoring.
8.	Copy, delete and list Event(s), by address and/or summary, on the unit.

**Note:** This maintains the proprietary Instantel Event format and security features, translating the existing Event data into a different format. The available formats are XML, CSV and ASCII.

9. Copy and delete the Monitor Log.

**Note:** This maintains the proprietary Instantel Monitor Log format, translating the existing Log data into a different format. The available formats are XML, CSV and ASCII.

10. Reset the unit remotely.
11. Obtain the unit and program Timeout responses.

### Purchasing

Third Party Access - Series IV may be purchased as a single-unit software product (one license), and an additional single-seat license fee for each additional unit. An annual, per-seat license renewal fee applies for each seat. Please contact your Dealer Representative for additional information and pricing.

**Corporate Office:**  
309 Legget Drive,  
Ottawa, Ontario K2K 3A3  
Canada

**US Office:**  
808 Commerce Park Drive,  
Ogdensburg, New York 13669  
USA

Toll Free: (800) 267 9111  
Telephone: (613) 592 4642  
Facsimile: (613) 592 4296  
Email: sales@instantel.com



© 2012 Xmark Corporation. Instantel, the Instantel logo, Auto Call Home, AutoRecord, Blastmate, Blastware, Histogram Combo, InstaLink, and Minimate are trademarks of Stanley Black & Decker, Inc., or its affiliates.

StanleyBlack&Decker

720B6101 Rev 01 - Product Specifications are Subject to Change