

# Instruction Sheet

## Micromate® Portable Field Printer

### Purpose

This bulletin describes the procedure for connecting the InstanTEL authorized Citizen® CMP-30BTU Portable Field Printer (Part No. 72100101) to the Micromate and printing event reports in the field. The use of unauthorized printers is not approved or supported by InstanTEL.

### Explanation



Many applications require hard copy reports to be printed in the field. Rather than including the cost and ongoing maintenance of a dedicated built-in printer, the Micromate provides a USB interface to an external portable printer that can be used with all of your Micromate units. If hard copy reports are required, this battery operated printer can be conveniently transported to the site and easily connected to the Micromate to print the event reports right in the field.

### Equipment Required

- 1) InstanTEL® Micromate
- 2) Citizen CMP-30BTU Portable Field Printer (Part No. 72100101)
- 3) USB Mini to USB Cable (supplied with 72100101)

### Printing Events

- 1) Ensure the internal printer battery has been charged and adequate paper is available.
- 2) Turn the printer on by pressing the power button (Image A).
- 3) Connect the supplied USB cable to the Printer (Image A).
- 4) Connect the free end of the USB cable inserted into the Micromate USB port (Image A).
- 5) Press the Event List icon or Down arrow on the Micromate to access the Event List (Image C).
- 6) Ensure the Printer icon appears at the top of the Micromate display (Image B and C).
  - a. If the icon is not available, make sure the printer has been turned on, and that the USB cable has been securely inserted.
- 7) Select the Event(s) to be printed.
- 8) Press the Printer icon.
- 9) Confirm which Events are to be printed.



**Corporate Office:**  
309 Legget Drive,  
Ottawa, Ontario K2K 3A3  
Canada

**US Office:**  
808 Commerce Park Drive,  
Ogdensburg, New York 13669  
USA

Toll Free: (800) 267 9111  
Telephone: (613) 592 4642  
Facsimile: (613) 592 4296  
Email: sales@instanTEL.com



© 2016 Xmark Corporation. InstanTEL, the InstanTEL logo, Micromate, Blastware, and Auto Call Home are trademarks of Stanley Black and Decker or its affiliates.

StanleyBlack&Decker

72100401 Rev 03 - Product Specifications are Subject to Change